

HOW IS INSTALLING DEVONSTONE DIFFERENT FROM PAVERS?

DevonStone requires 1-3/8" low profile edge restraint suitable for its thinner profile, not standard height edge restraint. Plate compactors may not be used on DevonStone, instead use a dead blow hammer or a long block of wood that can be placed over the DevonStone unit and struck with a hammer to seat the units in the setting bed. Uniform spacing for Saw Cut DevonStone can be achieved with tile nips.

MY DEVONSTONE SLABS HAVE A WHITE HAZE ON THEM. WHAT IS IT?

You are probably referring to efflorescence, a natural and common occurrence in concrete and brick products. Efflorescence is the result of natural salts in the materials used in product migrating to the surface of the slabs.

This is not a defect nor harmful to the slabs and will usually weather away with time.

HOW DO I CUT DEVONSTONE?

DevonStone can be easily cut with any power saw with a diamond blade. Always wear protective glasses and a mask when cutting with a power saw. If using water during the cutting process, be sure to immediately clean and residue that may be left on the stone or staining may result. Do not use a hammer or chisel to cut DevonStone.

CAN I USE DEVONSTONE ON MY DRIVEWAY?

No. DevonStone is not suitable for any vehicular traffic.

CAN I USE DEVONSTONE INSIDE?

Absolutely, just install it the same way you would tile, with a thinset adhesive.

CAN I USE DEVONSTONE WITH MY EP HENRY PAVERS?

Yes you can, but you must account for the difference in thickness. Most pavers are 2 3/8" or 3 1/8" thick; DevonStone is 1 5/8" thick. Do not attempt to compensate for the variability in thickness with the bedding material.

Important Notes:

DO NOT use a plate compactor on DevonStone.

It is recommended if you choose to seal DevonStone slabs, use only Techni-Seal Sealant for Wet Cast Pavers.

